Secure Payment Systems HYPERCOM T7p GIFT CARD INSTRUCTIONS

1. Activating a gift card

- a. Press the "Card Verify" key (B), and then the "3" key and press "Enter"
- b. Press "1-ACTIVATE" and then press "Enter"
- c. Swipe the gift card
- d. Enter the reference number printed at the back of the card and press "Enter"
- Enter the amount of the activation and press "Enter"

2. Making a Sale

- a. Press the "Card Verify" key (B) and then the "3" key and press "Enter"
- b. Press the "3" key and press "Enter"
- c. Swipe the gift card
- d. Enter the amount of the purchase and press "Enter"

3. Voiding a Sale

- a. Press the "Void" key (N)
- b. Enter the invoice number found on the receipt or audit report
- c. Verify that the amount is correct for the transaction and press "Enter"

4. Crediting a Sale

- a. Press the "Card Verify" key (B) and then the "3" key and press "Enter"
- b. Press "4" to run the transaction as "Refund"
- c. Swipe the gift card
- d. Enter the item number found on the receipt and press "Enter"
- e. Enter the amount of the refund and press "Enter"

5. Balance Inquiry

- a. Press the "Balance Inquiry" key (G)
- b. Press the "3" key and press "Enter"
- c. Swipe the gift card

6. Adding Value to a gift card

- a. Press the "Card Verify" key (B) and then the "3" key and press "Enter"
- b. Press the "2" key and press "Enter"
- c. Swipe the gift card
- d. Enter the amount to add to the card balance and press "Enter"

The letters in parenthesis "()" indicate the letter that appears over the key indicated

Secure Payment Systems Customer Service/ Technical Support – 888.313.7842

Secure Payment Systems HYPERCOM T7p GIFT CARD INSTRUCTIONS

Rev 2.0

Activating a gift card

- a. Press the "Card Verify" key (B) and then the "3" key and press "Enter"
- b. Press "1-ACTIVATE" and then press "Enter"
- c. Swipe the gift card
- d. Enter the reference number printed at the back of the card and press "**Enter**"
- e. Enter the amount of the activation and press "Enter"

2. Making a Sale

- a. Press the "Card Verify" key (B) and then the "3" key and press "Enter"
- b. Press the "3" key and press "Enter"
- c. Swipe the gift card
- d. Enter the amount of the purchase and press "Enter"

3. Voiding a Sale

- a. Press the "Void" key (N)
- b. Enter the invoice number found on the receipt or audit report
- c. Verify that the amount is correct for the transaction and press "Enter"

4. Crediting a Sale

- a. Press the "Card Verify" key (B) and then the "3" key and press "Enter"
- b. Press "4" to run the transaction as "Refund"
- c. Swipe the gift card
- d. Enter the item number found on the receipt and press "Enter"
- e. Enter the amount of the refund and press "Enter"

5. Balance Inquiry

- a. Press the "Balance Inquiry" key (G)
- b. Press the "3" key and press "Enter"
- c. Swipe the gift card

6. Adding Value to a gift card

- a. Press the "Card Verify" key (B) and then the "3" key and press "Enter"
- b. Press the "2" key and press "Enter"
- c. Swipe the gift card
- d. Enter the amount to add to the card balance and press "Enter"

The letters in parenthesis "()" indicate the letter that appears over the key indicated

7. Transferring funds from one gift card to another (Balance Transfer)

- a. Press the "Card Verify" key (B) and then the "3" key and press "Enter"
- b. Press the arrow key (above the yellow "NO" key) to go to the next menu
- c. Press the "6" key for Balance Transfer
- d. Swipe the gift card from which the balance is to be transferred
- e. Swipe the gift card the balance is to be transferred to

8. Reprint Receipt

- a. Press the "**Reprint**" key (R)
- b. Enter the invoice number found on the original receipt
 - I. If there is not an original copy, press the "Reports" key
 - II. Press "3" for Audit and then press "Enter"

9. Closing a Batch

- a. If not on "Auto Settle", press the "Settlement" key (E)
- b. Enter the password and press "Enter" The default password is four zeros (0000)
 - I. The Terminal will scan the batch and then display totals and ask if they are correct.
 - II. If satisfied with totals press "Yes" or "Enter". The terminal will dial the SPS processing center, clear the batch, and print a totals report.

10. Printing a Summary Report

- a. Press the "Reports" key (M)
- b. Press the "4" key for Summary and press "Enter"

11. Printing an Audit Report

- a. Press the "Reports" key (M)
- b. Press the "3" key for Audit and press "Enter"
- c. Enter the Host number and press "Enter" The gift card host is usually "03"

12. Printing Batch History Report

- a. Press the "Reports" key (M)
- b. Press "5" for History and press "Enter"
- c. Type **03** for SPS and press "Enter"
- d. Type the desired start date in Month, Day, and Year format, and then press "Enter"

7. Transferring funds from one gift card to another (Balance Transfer)

- a. Press the "Card Verify" key (B) and then the "3" key and press "Enter"
- b. Press the arrow key (above the yellow "NO" key) to go to the next menu
- c. Press the "6" key for Balance Transfer
- d. Swipe the gift card from which the balance is to be transferred
- e. Swipe the gift card the balance is to be transferred to

8. Reprint Receipt

- a. Press the "Reprint" key (R)
- b. Enter the invoice number found on the original receipt
 - I. If there is not an original copy, press the "Reports" key
 - II. Press "3" for Audit and then press "Enter"

9. Closing a Batch

- a. If not on "Auto Settle", press the "Settlement" key (E)
- b. Enter the password and press "Enter" The default password is four zeros (0000)
 - I. The Terminal will scan the batch and then display totals and ask if they are correct.
 - II. If satisfied with totals press "Yes" or "Enter". The terminal will dial the SPS processing center, clear the batch, and print a totals report.

10. Printing a Summary Report

- a. Press the "Reports" key (M)
- b. Press the "4" key for Summary and press "Enter"

11. Printing an Audit Report

- a. Press the "Reports" key (M)
- b. Press the "3" key for Audit and press "Enter"
- c. Enter the Host number and press "Enter" The gift card host is usually "03"

12. Printing Batch History Report

- a. Press the "Reports" key (M)
- b. Press "5" for History and press "Enter"
- c. Type 03 for SPS and press "Enter"
- d. Type the desired start date in Month, Day, and Year format, and then press "Enter"

Secure Payment Systems HYPERCOM T7p ECHECK INSTRUCTIONS

The letters in parenthesis "()" indicate the letter that appears over the key indicated



State Codes Alabama Alaska Arizona Arkansas California Colorado Connecticut Wash DC Delaware Florida Georgia Hawaii Idaho Illinois Indiana Iowa Kansas Kentucky Louisiana Maine Maryland Massachusetts Michigan Minnesota Mississippi Missouri Montana Nebraska Nevada New Hamp

Press the "Check" key (H) on the keypad (The check key is the 2nd orange key in the 2nd row)

- a. Press the "1" numeric key from the keypad for manual bank deposit (Check Auth) (i.e. A business check or a check that was already run and received a "Rerun as Paper" response) and press "Enter". (The enter key is the same as "Yes" key and is the green key located at the bottom)
- b. Press the "2" numeric key from the keypad if this check is to be electronically deposited (ACH Check) (and the check will be handed back) and press "Enter". (Business checks must be deposited as paper and may not be converted)
- Guarantee Yes or No? (if "Check Auth" then the word ACH will not appear)
 - a. If currently subscribing to the SPS guarantee program "Yes" must be selected at this prompt in order to for claims to be covered. The terminal will not prompt for ACH or non-ACH if subscribing to verification services only.
- ACH Check Amount? ...
 - a. Enter the \$ amount and press "Enter"
- ACH Check Drivers License Number (if not prompted then the terminal will proceed to (5) below)
 - a. Swipe the magnetic stripe license
 - If a good swipe the terminal proceeds to (5) below
 - If a bad swipe or no magnetic strip then:



- Begin manual entry of the customer's driver's license number as exactly seen on the license. If letters are required, press the "Shift" key (The shift key is the first key in the last row) and the desired letter simultaneously. When finished, press "Enter" to see:
- State Code Enter the two digit state code and press "Enter" (the sate code table is located to the left of this page)
- DOB prompt follows the phone # prompt if manual.

ACH Check Insert Check

- a. Slide the check thru the imager or check reader
 - If a bad read then try again or if unable to get a good read press the "Cancel" key (The cancel key is the pink key in the first row) and start over when the terminal prompts Check Auth or ACH Check at step (1) above and then manually enter the routing number at the "Enter MICR Number" prompt. The moment manual entry is begun the terminal will display:
 - Enter Account # ... when finished press "Enter"
 - Enter Routing # ... when finished press "Enter"
- Enter Check # ... Enter check number located in the upper right hand corner of check.
- Enter phone #.... Enter the customer's home phone beginning with area code.
- Date of birth #...Enter the customers date of birth.
- Terminal Begins Dialing Sequence (Dialing. Connecting, Receiving, Transmitting, etc.)
 - If the terminal displays: "OKAY NNNN" the terminal will finish printing the authorization receipt, which the customer must sign to complete the transaction. The terminal will then prompt to print another receipt for the customer copy.

Quebec

Saskatchewan Yukon Terr

Secure Payment Systems HYPERCOM T7p ECHECK INSTRUCTIONS

10. Miscellaneous Administrative Issues

- a. Reprint Receipt (in case there was a printer problem)
 - i. Press the "Reprint" key (R) (The reprint key is the last key in the third row) and enter in the invoice number found on the original copy. If the original copy is not available press the "Reports" key (M) (The reports key is the first key in the third row) on the terminal, press "3" for audit and then press "Enter". (Or call customer service at (888) 313-7842 and ask for the last 6 digits of the item number of the transaction)
- b. If the terminal displays: "Call Ctr NN" (where NN = a two digit number) immediately call the SPS voice authorization center for operator approval. Upon receiving approval:
 - i. Force the authorization into the batch (similar to forcing a credit card transaction), by immediately rerunning the transaction just like the original transaction (do not delay, the customer needs to sign a printed receipt)
- c. If the terminal displays an error response such as: "Micr/Chk # Error" or "DL Error" or "DOB Error" or "Phone # Error" or "State

 Code Error" then rerun the transaction from the beginning. If the terminal responds with "Rerun As Paper" then rerun the transaction from the beginning and select "1" at step #1 above.

11. SPS Batch Close (if using the ACH check conversion service)

- a. If not on "Auto Settle", press the "Settlement" key (E) (The settlement key is the fifth key in the first row). At the "Enter password" prompt, enter the password (generally it is four zeros (0000)) and then press "Enter".
 - i. The Terminal will scan the batch and then display totals and ask if they are correct.
 - ii. If satisfied with totals press "Yes" or "Enter". The terminal will dial the SPS processing center, clear the batch, and print a totals report.

12. Printing a Summary Report

- a. Press the "Reports" key (M) on the keypad (The Reports key is the first key in the third row)
- b. Press "4" for summary and then press "Enter"

13. Printing an Audit Report

- a. Press the "Reports" key (M) on the keypad (The Reports key is the first key in the third row)
- b. Press "3" for audit and then press "Enter"
- c. Enter the Host number and press "Enter"

14. Printing Batch History Report

- a. Press the "Reports" key (M) on the keypad (The Reports key is the first key in the third row)
- b. Press "5" for history and then press "Enter"
- c. Type 03 for SPS and press "Enter"
- d. Type the desired start date in Month, Day, and Year format, and then press "Enter"
- 15. Automatic Image transmission --- The terminal automatically causes images to be transmitted after the batch is settled. A receipt will be printed denoting the number of images uploaded if successful, or the number of images not uploaded if unsuccessful. Please call the SPS Customer Service line if image uploads are unsuccessful for more than two days in a row.

16. Manual Image Transmission (in case of failed automatic transmission - if using an imager)

- i. Press "FUNCTION" key (D) (The function key is the blue key in the first row) and then type 80 and press "Enter"
- ii. Terminal will display 1 = SEND 2 = CLR (clear images) 3 = INFO (states number of images in a storage). Select 1 to send images.

Note: Paper based transactions (where non ACH is selected) are not included in terminal reporting / batches

Cable Requirements:

If using a check reader or imager you will require a FIP11 adaptor.

Supported check readers;

Magtek Mini MICR Cable Part Number: 22517509

Supported imagers;

Magtek MICRImage Cable Part Number: 22410310*
RDM EC5000 series Cable Part Number: 05465-00 REV A
RDM EC6000 series Cable Part Number: 05465-00 REV A

* Optional adaptor for direct connection to the PIN Port; Part Number 810278

Secure Payment Systems HYPERCOM T7p LOYALTY CARD INSTRUCTIONS

The letters in parenthesis "()" indicate the letter that appears over the key indicated

1. Issuing a Loyalty Card

- a. Press the "Card Verify" key (B) on the keypad (The card verify key is the orange key in the first row). Press the "4" numeric key from the keypad and press "Enter". (The enter key is the same as "Yes" key and is the green key located at the bottom)
- b. Press "2-ISSUE" to activate the Loyalty Card and then press "Enter"
- c. Swipe the Loyalty Card through the slot on the right side of the terminal
- d. Type in the full reference number printed on the back of the card and press "Enter"
- e. Terminal begins Dialing sequence (Dialing, Processing, etc.) It will give an approval and print a copy of the issue receipt and will prompt to print another receipt for the customer copy.



2. Accumulation

- a. Press the "Card Verify" key (B) on the keypad (The card verify key is the orange key in the first row)
- b. Press the "4" numeric key from the keypad and press "Enter". (The enter key is the same as "Yes" key and is the green key located at the bottom)
- c. Press the "1" numeric key from the keypad, to run the transaction as a Accumulation and press "Enter"
- d. Swipe the card through the slot on the right side of the terminal
- e. Type in the amount of accumulation and press "Enter"
- f. Terminal begins Dialing sequence (Dialing, Processing, etc.) It will give an approval and print a copy of the accumulation receipt and will prompt to print another receipt for the customer copy.

3. Redemption

- a. Press the "Card Verify" key (B) on the keypad (The card verify key is the orange key in the first row)
- b. Press the "4" numeric key from the keypad and press "Enter"
- c. Press "3" to run the transaction as "Redeem"
- d. Swipe the Loyalty Card through the slot on the right side of the terminal
- e. Type in the level of redemption and press "Enter"
- f. Terminal begins Dialing sequence (Dialing, Processing, etc.) It will give an approval and print a copy of the redemption receipt and will prompt to print another receipt for the customer copy

4. Performing a Balance Inquiry

- a. Press "Balance Inquiry" on the keypad (G) (The balance inquiry key is the first key in the second row)
- b. Press the arrow key on the keypad (above the yellow "clear" key) to go to the next menu
- c. Press "4" for balance inquiry
- d. Swipe the card through the slot on the right side of the terminal
- e. Terminal begins Dialing sequence (Dialing, Processing, etc.) It will give an approval and print a copy of the balance inquiry receipt

5. Transferring a Loyalty Card Balance

- a. Press the "Card Verify" key (B) on the keypad (The card verify key is the orange key in the first row)
- b. Press the "4" numeric key from the keypad and press "Enter"
- c. Press the arrow key on the keypad (above the yellow "clear" key) to go to the next menu
- d. Press the arrow key on the keypad (above the yellow "clear" key) to go to the next menu
- e. Press "6" for balance transfer
- f. Swipe the card from which the balance is to be transferred
- g. Swipe the card on which the balance to be transferred to
- h. Terminal begins Dialing sequence (Dialing, Processing, etc.) It will give an approval and print a copy of the balance receipt and will prompt to print another receipt for the customer copy

Secure Payment Systems HYPERCOM T7p LOYALTY CARD INSTRUCTIONS

6. Miscellaneous Administrative Issues

- a. Reprint Receipt (in case there was a printer problem)
 - i. Press the "Reprint" key (R) (The reprint key is the last key in the third row) and enter in the invoice number found on the original copy. If the original copy is not available press the "Reports" key (M) (The reports key is the first key in the third row) on the terminal, press "3" for audit and then press "Enter".
- b. Void Transaction (to cancel a transaction)
 - i. On the keypad, press the "Void" key (N) (The void key is the orange key in the third row) and type in the invoice number found on the receipt or audit report. Verify that the amount is correct for the transaction and press "Enter"

7. SPS Batch Close

- a. If not on "Auto Settle", press the "Settlement" key (E) (The settlement key is the fifth key in the first row). At the "Enter password" prompt, enter the password (generally it is four zeros (0000)) and then press "Enter".
 - i. The Terminal will scan the batch and then display totals and ask if they are correct.
 - ii. If satisfied with totals press "Yes" or "Enter". The terminal will dial the SPS processing center, clear the batch, and print a totals report.

8. Printing a Summary Report

- a. Press the "Reports" key (M) on the keypad (The Reports key is the first key in the third row)
- b. Press "4" for summary and then press "Enter"

9. Printing an Audit Report

- a. Press the "Reports" key (M) on the keypad (The Reports key is the first key in the third row)
- b. Press "3" for audit and then press "Enter"
- c. Type in the Host number and press "Enter"

10. Printing Batch History Report

- a. Press the "Reports" key (M) on the keypad (The Reports key is the first key in the third row)
- b. Press "5" for history and then press "Enter"
- c. Type 03 for SPS and press "Enter"
- d. Type the desired start date in Month, Day, and Year format, and then press "Enter"